

TXJTServer

JTServer Component "Slave"

Using :

Providing Object . Property access for JT Client

SubObjects :

TXRTag

Tag Object . Property Referange

Link Component :

JTClient

Events :

OnSendValue

Afrer Send Transaction

Commands :

Start

Start Provider

Stop

Stop Provider

Propertyes :

AutoStart

Start After Run

IOInfo

Send IO information To AlarmInfo

ActiveLed

Active State

Value

Link Point



